

Bladder Evacuation Tool Instructions

Single Port AMTC-M2033



1. Insert Bladder Evacuation Tool into vacuum hose. Tool is designed to fit 1", 1-1/2", and 2" vacuum hoses.



2. Turn the knurled locking nut clockwise on the oral inflation tube until it stops



3. With the vacuum on, insert the oral inflation tube mouth piece into the port on the Bladder Evacuation Tool.

Depress the tube and hold firmly in place as the bladder deflates completely.



Upon completion of the evacuation, turn the knurled locking nut counter clockwise to the locked position.

Dual Port AMTC-M2026



1. Insert Bladder Evacuation Tool into vacuum hose. Tool is designed to fit 1", 1-1/2", and 2" vacuum hoses.



2. Turn the knurled locking nut clockwise on the oral inflation tube until it stops



3. With the vacuum on, insert the oral inflation tube mouth pieces into the port on the Bladder Evacuation Tool.

Depress the tube and hold firmly in place as the bladder deflates completely.

Upon completion of the evacuation, turn the knurled locking nut counter clockwise to the locked position.